

Sangoma P325 IP Phone

Offering even more functionality, the P325 delivers 6-line keys, a paging key for 20 pages of virtual keys.



P-Series IP Phones

Sangoma's line of P-Series mid-range phones are designed to deliver the features you need for every user type at a competitive price point. All models include high definition audio, unprecedented plug-and-play deployment, and advanced built-in applications that include voicemail, call log, contacts, phone status, user presence, parking, and more.



P325 Phones

Features



- **DIALING CALLS:** Pick up the handset or press a line key and dial a number. You can also enter a number and press the Dial softkey. You can also use *Contacts* or *Call Log* to find the number you want, then press the Dial softkey. If you use *Contacts*, you can dial a coworker's Voicemail.
- **RECEIVING CALLS:** Pick up the handset, or press a softkey: Answer, Ignore, Transfer, or Send VM. Ignore makes the call stop ringing but uses your Call Rules. Transfer lets you transfer the call. Send VM sends the call to your voicemail regardless of your Call Rules.
- **REDIAL:** Press the Redial button to redial the last call you made. (If you have multiple lines, Redial automatically uses the correct line)
- **HOLD:** During a call, press Hold. The line key flashes red. Press either the flashing line key or the Resume softkey to resume the
- **TRANSFER:**
 - ASSISTED** – During a call, press the Transfer button. Enter a number or press the Contacts softkey to find a number. Press the Dial softkey. When someone answers, inform them of the call to be transferred. Press the Transfer softkey, (*or Transfer button again*) and the transfer is completed.
 - UNASSISTED (blind)**– During a call, press the Transfer button. Enter a number or press the Contacts softkey to find a number. Press the Transfer softkey, and the transfer is completed.
 - TRANSFER TO VOICEMAIL** – If you used *Contacts* for a transfer, you can press the Transfer VM softkey instead of Transfer. That transfers the call to that contact's voicemail.
- **MENU:** The menu application is accessed using the Menu softkey. It contains configuration and information screens for your phone.
- **CONFERENCE:** (*3-WAY CALLS*). During a call, press the Conference softkey. Dial the third participant's number or use *Contacts*. Press the Conference softkey again to connect all participants. To split a conference into separate calls with each participant, press the Split softkey and select the participant to drop from the call.
- **PARK:** During a call, press the Park softkey. Then you or a coworker can answer the call from another phone by either dialing that Parking extension or by pressing the *Parked Calls* softkey and answering the call. From the idle screen: press the More... softkey, then *Parked Calls*.
- **CONTACTS:** *Contacts* are used for rapid dialing, and for finding detailed information about someone. You can use *Contacts* from within *Transfer* and *Conference*. To see the Detail page for a contact, press the Show softkey in a list of contacts. Details include the person's Status.
 - You can assign *Contacts* as Rapid Dials on your phone. (*See Switchvox User Portal Guide*)
- **VOICEMAIL:** Press the  button to dial your voicemail extension.
- **STATUS:** Press the Status softkey to change your status. **Do Not Disturb** sends incoming calls to your voicemail (*and declines queue calls*). Your coworkers see your Status on their phone or Switchboard. You can use Call Rules to manage incoming calls based on different Status Options.
- **INFO:** Press the Info softkey followed by a line key to display a detail page for that key